









Pivotal Ladder

Installation Instructions

Important

These instructions are not intended to be a complete lesson in the installing of pivotal ladders but a procedural guide to competent tradespeople or DIYers.

Tools Required

The screws supplied with this ladder require a 5/16" nut setter for easy installation. This can be used with a 18v battery drill or a standard power drill. Apart from this, only standard carpentry tools are required.

Installing The Ladder

Note: Sellwood pivotal ladders are custom-built to a predefined vertical height upon order confirmation, requiring no further adjustment.

- Position the pivotal ladder in the desired location, ensuring that the ladder feet are flush on the ground.
- 2. Insert the fixing brackets into the sliding bar slot ensuring the pins are at the top.
- 3. Secure the ladder in place by screwing through the fixing brackets using the fixings provided. Ensure that the screws penetrate solid timber or support material.
- 4. Sellwood pivotal ladders are set at a 70-degree angle. Double-check that the ladder feet and treads are level with the ground.

www.sellwood.co.nz sales@sellwood.co.nz 0800 288 427 (ATTICS) 3/75 Apollo Drive, Rosedale